



NOTES:

- 1) ROOT PRUNE ALL SHREDDED OR DAMAGED ROOTS.
- 2) ENSURE THAT ALL WOUNDS TO THE ROOT SYSTEM ARE CLEAN CUT BEFORE PLANTING. APPLY DUSTING SULFUR TO ALL ROOTS.
- 3) SPRAY CANES IMMEDIATELY AFTER PLANTING.
- 4) UNTIE CANES AS SOON AS PLANTING IS COMPLETED.

OCOTILLO PLANTING

NTS

ISSUED:		STANDARD DETAIL		DETAIL NO.
REVISED:		OCOTILLO PLANTING		404
				SHEET 1 OF 1